

Serial BV Conversion – ICT PA7

1. ALL dips on the side OFF.
2. There's also 4 dips under the cover on the body of the BA
 - a. For Serial Dip Switch
 - i. ON: 1 & 2
 - ii. OFF: 3 & 4
 - b. For Pulse Dip Switch
 - i. ON: 1, 2, 3
 - ii. OFF: 4
3. Replace the 2 connections to the BA.
4. Reboot.

Convert PP3/Spooky Tall/Golden Dragon Link Operator Menu PA7 from PULSE to SERIAL

1. Press Operator menu button. Password is "0 0 0 0 0 0"
2. Go to the Global settings then press Printer/BV on the left
3. Scroll down and Enable Serial BV *ON*
4. Change Serial BV Type to **PA7**
5. Change Serial BV Port Number to **COM6 (QXI 6000) or COM1 (EFCO)**
6. Exit settings
7. If PA7 lights are
 - a. ON – ready to test
 - b. OFF – reboot the cabinet

Need additional assistance? Call TECH-DIRECT 920-850-7409

Additional Operator Manuals

