



Genmega Electronic Pin Pad (EPP) Master Key Clear

Process for clearing the existing Master Key stored in the EPP and creating a new Master Key.

Default Password is always EIGHT ZEROS (00000000).

NOTE: It is strongly recommended that you take your time for this process because if a mistake is made then the process will have to restart from step 6.

1. Connect a USB keyboard
2. Press F1 on the keyboard to open Admin Menu
3. Select ATM OPERATOR
4. Enter six 3's to ATM setting
5. Select Host Setup
6. Select Key Management
7. Enter 1st password: 12345678
Enter 2nd password: 90123456
8. Select EPP Clear
9. **Clear All Keys?** press **Yes** to continue
10. **Out of Service**, press KEY MANAGEMENT
11. INPUT DEFAULT SECURE PWD 1 (eight zeros)– 00000000
INPUT DEFAULT SECURE PWD 2 (eight zeros)– 00000000
12. Change Secure **PASSWORD 1** – 12345678
13. Enter **PASSWORD 1** again
14. Change Secure **PASSWORD 2** – 90123456
15. Enter **PASSWORD 2** again
16. **CHANGE PASSWORD SUCCESSFUL**
17. Please Wait for max 1 minute
18. Enter your new, changed password 1 and password 2
19. **WARNING!**, press **YES** to save and switch to Operation Mode